

# VOICE REMOTE QUICK START




# WELCOME TO YOUR NEW TIVO VOICE REMOTE!

You're just a few easy steps from using the new TiVo Experience with Voice Remote.

## 1 Verify that your box is running TiVo Experience 4.

Using your *old* remote, press the TiVo button. If you see a screen titled "Home," you're already running TiVo Experience 4! **You can skip to Step 2.**



If you see the "TiVo Central" screen instead of the Home screen, follow the steps below to upgrade to the new experience. **Please note: your new voice remote will not work until you upgrade.** This upgrade may take up to 15 minutes.

1. From the TiVo Central screen, choose *Apps > Get New Experience*. Follow the on-screen instructions.
2. Restart your TiVo box. Go to *Settings & Messages > Help > Restart Box*.
3. When your box restarts, you'll see the TiVo Home screen, which replaces TiVo Central screen.

2 **If your package included a USB connector**, insert the USB extension cable (with the USB connector attached) into one of your TiVo box's USB ports. For best results, place the connector (at the end of the cable) near, beside or on top of the TiVo box.



**No USB connector in your package? You're all set. You can skip to Step 3.**

**3 Pair your new remote.** Remove the back cover of the remote and insert two fresh AA batteries.

- The remote will attempt to automatically “pair” with your TiVo box. If the activity light at the top of the remote flashes yellow with each button-press, the remote is paired.
- If, instead, the activity light flashes red with each button press, you’ll need to manually pair the remote to the TiVo box. From the Home screen, choose the menu icon (☰), then choose *Settings > Remote, CableCARD & Devices (Remote & Devices on Mini) > Remote Control Setup > Remote Control Pairing* and follow the on-screen instructions.

**4 Program the buttons on your remote.** The power, volume, mute, and input buttons can be programmed to control your TV and A/V receiver (or sound bar).

- From the Home screen, choose ☰ > *Settings > Remote, CableCARD & Devices (Remote & Devices on Mini) > Remote Control Setup* and follow the on-screen instructions.

Activity light




# YOU'RE ALL SET UP!

## TURN TO THE NEXT PAGE TO LEARN HOW TO USE YOUR NEW REMOTE

# ASK FOR WHAT YOU WANT

The TiVo voice remote is the only remote that lets you speak in natural language and gives you the ability to narrow your search results as you go. Search for shows, tune to a channel, ask for recommendations...it's all at your fingertips.



**To issue a voice command, press and hold the  button and speak naturally into the microphone.**

## SIMPLE

Try saying...

- Find me a Bill Murray movie.
- Show me movies from the 80s.
- Launch Netflix.
- My Shows.
- Warriors-Cavaliers game tonight.
- US Open Tennis.
- Great British Baking Show.

## DETAILED

Try saying...

- Bill Murray comedy from the 80s.
- Movies with Tom Cruise & Nicole Kidman.
- Comedy special Jerry Seinfeld
- Action movies with 'The Rock.'
- Kids baking shows
- George Clooney dramas

## REVISABLE

Try saying...

- Show me movies with Ryan Gosling ... *[when results are shown, add another search term]* and Emma Stone.
- Movies with Harrison Ford ... *[when results are shown, add another search term]* one from the 90s ... *[and another]* action only."

## SMART

Try saying...

- What's that movie where the woman says "I'll have what she's having?"
- "I'm going to make him an offer he can't refuse."
- Find that TV show where John Travolta was in high school.
- "Hasta la vista, baby."